

# How to cut antislip decking



Due to the hard wearing and highly durable nature of our Antislip and CitiDeck resin/aggregate inserts, the following cutting procedure should be followed:

- ▲ At the required point mark a straight line across the boards.
- ▲ Use a 125mm angle grinder, with either a 3 or 5mm thick cutting disc (stone or steel both work equally the same) to cut through the resin/aggregate insert.
- ▲ Use a hand or mechanical timber saw to cut the remaining timber.
- ▲ The cut ends should then be coated with cut end seal.



## Tell me more

Call 01283 722588

Email [info@marley.co.uk](mailto:info@marley.co.uk)

Or visit [marley.co.uk/products/decking](http://marley.co.uk/products/decking)

Marley, Lichfield Road, Branston, Burton upon Trent, DE14 3HD

