

RUBBER MULCH MAINTENANCE SCHEDULE

Rubber Mulch is a low maintenance product. However, it should undergo routine inspection and maintenance to keep it in optimum condition.

Routine Visual Inspection

A routine visual inspection is recommended.

Litter / Leaves

- Litter, leaves and surface debris should be removed regularly using a leaf blower.

Weeds

Note: Every effort is made to ensure that weeds do not grow through the mulch. A weed suppression layer (geotextile membrane) is laid between the sub-base and the mulch. This process is verified through photographs, which are taken at regular intervals during the installation.

- However, weeds may occasionally appear on the surface, usually as a result of migratory seeds. Small numbers of weeds can be removed by hand without damaging the surface. If the weeds are removed by hand, it is important to ensure that the full root of the weed is extracted, not broken off. Localised areas of weed seedling infestation can be treated with domestic weed-killers without causing damage to the surface.